



AA-1 YANKEE SERVICE MANUAL

*American Aviation Corporation*

CAJANDERKARI  
MIKKELINTIE 351  
53830 LAPPEENRANTA

# **The American Yankee**

## **Service Manual**

**DECEMBER, 1969**

**American Aviation Corporation**  
318 Bishop Road, Cleveland Ohio 44143  
Cable Address: AMERICAV



## TABLE OF CONTENTS

SECTION		PAGE
1	GENERAL .....	1-1
	A. INTRODUCTION .....	1-2
	B. GENERAL DESCRIPTION .....	1-2
	SPECIFICATIONS .....	1-2
	3-VIEW .....	1-3
	SERIAL NUMBER AND TRIM PLATE .....	1-4
2	SERVICING .....	2-1
	A. GROUND HANDLING .....	2-2
	B. LEVELING .....	2-2
	C. WEIGHING .....	2-2
	D. LUBRICATION .....	2-2
	E. MOORING .....	2-2
	F. CLEANING .....	2-3
	G. JACKING .....	2-3
	H. LUBRICATION CHART .....	2-4
	I. INSPECTION .....	2-5
	SERVICE GUIDE .....	2-6
	ANNUAL OR 100 HOUR INSPECTION PROCEDURE .....	8 pages
3	AIRFRAME .....	3-1
	A. WING REMOVAL .....	3-2
	B. EMPENNAGE REMOVAL .....	3-2
	C. CANOPY REMOVAL .....	3-2
	D. COWLING REMOVAL .....	3-3
	E. TAILCONE REMOVAL .....	3-3
	F. WING TIP REMOVAL .....	3-3
	G. WING ROOT REMOVAL .....	3-3
	H. SEAT REMOVAL .....	3-3
	I. WINDSHIELD REMOVAL .....	3-4
	J. CONSOLE REMOVAL .....	3-4
4	LANDING GEAR .....	4-1
	A. MAIN LANDING GEAR .....	4-2
	B. NOSE LANDING GEAR .....	4-2
	C. WHEELS, TIRES, AND BRAKES .....	4-5
	D. TOE-IN AND CAMBER ADJUSTMENTS .....	4-7
	E. WHEEL FAIRINGS .....	4-7
5	CONTROL SYSTEM .....	5-2
	A. AILERONS .....	5-2
	B. ELEVATORS .....	5-2
	C. RUDDER .....	5-2
	D. FLAPS .....	5-2
	E. TRIM .....	5-2
	F. FLAP MOTOR .....	5-3
	G. CONTROL SURFACES REMOVAL .....	5-3



## TABLE OF CONTENTS

SECTION		PAGE
6	POWERPLANT .....	6-1
	A. GENERAL .....	6-2
	B. SPECIFICATIONS .....	6-2
	C. ENGINE REMOVAL .....	6-2
	D. ENGINE CONTROLS .....	6-2
	E. INDUCTION SYSTEM .....	6-3
	F. EXHAUST SYSTEM .....	6-4
	G. OIL SYSTEM .....	6-4
	H. PRIMING SYSTEM .....	6-4
	I. IGNITION SYSTEM .....	6-5
	J. COOLING SYSTEM .....	6-7
	K. PROPELLER .....	6-7
	L. IDLE SPEED AND MIXTURE ADJUSTMENT .....	6-7
	ENGINE TROUBLE SHOOTING CHART .....	6-8
7	FUEL SYSTEM .....	7-1
	A. GENERAL .....	7-2
	B. FUEL TANK .....	7-2
	C. FUEL TANK DRAIN .....	7-4
	D. FUEL CAP .....	7-4
	E. FUEL SELECTOR VALVE .....	7-4
	F. FUEL PRESSURE GAUGE .....	7-4
	G. ELECTRIC FUEL PUMP .....	7-4
	H. FUEL MEASUREMENT SYSTEM .....	7-5
	FUEL SYSTEM TROUBLE SHOOTING CHART .....	7-5
8	UTILITY SYSTEMS .....	8-1
	A. BRAKE SYSTEM .....	8-2
	BRAKE SYSTEM TROUBLE SHOOTING CHART .....	8-3
	B. CABIN HEATING AND VENTILATING SYSTEM .....	8-4
9	INSTRUMENTATION .....	9-1
	A. MAGNETIC COMPASS .....	9-2
	B. CLUSTER ASSEMBLY .....	9-2
	C. TURN AND BANK INDICATOR .....	9-2
	D. HOURMETER .....	9-2
	E. TACHOMETER .....	9-2
	TURN AND BANK INDICATOR TROUBLE SHOOTING CHART .....	9-2
	HOURMETER TROUBLE SHOOTING CHART .....	9-2
	MAGNETIC COMPASS TROUBLE SHOOTING CHART .....	9-3
	TACHOMETER TROUBLE SHOOTING CHART .....	9-3
	OIL PRESSURE GAUGE TROUBLE SHOOTING CHART .....	9-3
	OIL TEMPERATURE GAUGE TROUBLE SHOOTING CHART .....	9-3
	F. PITOT AND STATIC SYSTEM .....	9-6
	PITOT AND STATIC SYSTEM TROUBLE SHOOTING CHART .....	9-7
	G. VACUUM SYSTEM .....	9-9
	VACUUM SYSTEM TROUBLE SHOOTING CHART .....	9-9



## TABLE OF CONTENTS

SECTION		PAGE
10	STRUCTURAL REPAIR .....	10-1
	A. GENERAL .....	10-2
	B. TOOLS, JIGS, AND FIXTURES .....	10-2
	C. MATERIALS .....	10-2
	D. SERVICE KITS .....	10-2
	E. HONEYCOMB REPAIRS .....	10-2
	STRUCTURAL REPAIRS .....	10-3
	F. REPAIR OF FORMED THERMO-PLASTIC PARTS .....	10-3
	G. ENGINE MOUNT REPAIR .....	10-3
	H. CONTROL SURFACE REPAIR .....	10-3
	AIRFRAME MATERIALS CHART .....	10-4
11	ELECTRICAL SYSTEMS .....	11-1
	A. GENERAL .....	11-2
	B. BATTERY .....	11-2
	C. ALTERNATOR .....	11-2
	D. VOLTAGE REGULATOR .....	11-3
	E. AMMETER .....	11-3
	F. FLAP MOTOR .....	11-3
	G. LANDING LIGHT .....	11-3
	H. NAVIGATION LIGHT .....	11-3
	I. FLASHING BEACON .....	11-3
	J. INSTRUMENT LIGHTS .....	11-4
	K. DOME LIGHT .....	11-4
	ELECTRICAL SYSTEM TROUBLE SHOOTING CHART .....	11-4
	L. ELECTRICAL LOAD ANALYSIS .....	11-8
	APPENDIX A - WIRING DIAGRAMS	